

Project Name:

Location:

Engineer:

Submitted to:

Submitted by:

Reference:

Approval:







Date:

Construction:


Unit #:

Drawing #:



Used with	Single Setpoint mode			Dual Setpoint mode		
	BRC1E72RM	BRC1E72RF	BRC1E72RMF	BRC1E72RM2	BRC1E72RF2	BRC1E72RMF2
Model						
On/Off	X	X	X	X	X	X
Mode	X		X	X		X
Fan		X	X		X	X
Up, Down	X	X	X	X	X	X
Left, Right				X	X	X
Menu/Ok						
Cancel						

### DIMENSIONS:



### DOCUMENTATION:

Documentation available on [www.daikincity.com](http://www.daikincity.com) and/or [www.daikinac.com](http://www.daikinac.com):

- Installation Manual
- Operation Manual

Daikin North America LLC, 5151 San Felipe, Suite 500, Houston TX, 77056

[www.daikinac.com](http://www.daikinac.com) [www.daikincity.com](http://www.daikincity.com)

(Daikin's products are subject to continuous improvements. Daikin reserves the right to modify product design, specifications and information in this data sheet without notice and without incurring any obligations)